

# DIME-X

## Owner's Manual

---

1-POWER OFF FETTO LARocca

---

2-PULL OUT THE VALVE TO BE  
REPLACED BY DIME-X

---

3-PUT IN DIME-X, POWER ON  
AND RAWK...

---

TIP OF THE DAY: NEVER "HOT SWAP"  
DIME-X (=CHANGE WITH POWER ON)



www.himmelsstrutz.com