

DIME-X

Owner's Manual

1-POWER OFF FETTO LARocca

2-PULL OUT THE VALVE TO BE
REPLACED BY DIME-X

3-PUT IN DIME-X, POWER ON
AND RAWK...

TIP OF THE DAY: NEVER "HOT SWAP"
DIME-X (=CHANGE WITH POWER ON)



www.himmelstutz.com